

Camera Maker	Camera Model	DCR-2020PRO Telephoto2.2x	DCR-1850PRO Telephoto1.85x	DCR-1540PRO Telephoto1.54x	DCR-730 Wideangle 0.7x	DCR-6600PRO Wideangle 0.66x	DCR-5000 Wideangle 0.5x	DCR- CF185PRO 185°	DCR-FE180PRO 180°/Fish-Eye	DCR-250/DCR-150 Super Macro/Macro	MSN-202 Super Macro	MSN-505 Super Macro	MDR-079PRO Wideangle 0.79X	HD-7000PRO Wideangle 0.7X	
Canon	Powershot A520/A510	RA6252(Included)*25	*25	*25	*25		*25	RA6252(Included)*25	RA6252(Included)*25	Universal adapter (included) *25					
	Powershot A95/A80	RA6252(Included)*12	*12	*12	*12		*12	RA6252(Included)*12	RA6252(Included)*12	Universal adapter (included) *12					
	PowershotA85/A75/A70/A60	RA6252(Included)*13	*13	*13	*13		*13	RA6252(Included)*13	RA6252(Included)*13	Universal adapter (included) *13					
	PowershotA40/A30		*22	*22	*22				RA6252(Included)*22	Universal adapter (included) *22					
	PowershotA20/A10		*21	*21	*21				RA6252(Included)*21	Universal adapter (included) *21					
	Powershot G6	RA6258(Included) *11*3	RA5258 *11	RA5258 *11	RA5258 *11	RA5258 *11	RA5258 *11	RA5258 *11	RA6258(Included)*11	RA6258(Included) *11	Universal adapter (included) *11				
	Powershot G5/G3	RA6258(Included) *1*3	RA5258 *1	RA5258 *1	RA5258 *1	RA5258 *1	RA5258 *1	RA5258 *1	RA6258(Included) *1	RA6258(Included) *1	Universal adapter (included) *1				
	Powershot G1/G2		RT5246G1	RT5246G1	RT5246G1	RT5246G1	RT5246G1	RT5246G1	RA6252(Included)+RT5246G1	RA6252(Included)+RT5246G1	Universal adapter (included) *RT5246G1				
	Powershot S70/S60		RA5237*26	RA5237*26	RA5237*26			RA5237*26			Universal adapter (included) *26+RA5237				
	Powershot S2 IS	RA6252(Included)*18		RA5258*18	RA5258*18			RA5258*18	RA6258(Included)*18	RA6258(Included)*18	Universal adapter (included) *18	Universal adapter (included) *18	Universal adapter (included) *18		*18
	Powershot S1 IS	RA6252(Included)*14		*14	*14	*14	*14	*14	RA6252(Included)*14	RA6252(Included)*14	Universal adapter (included) *14				
	Powershot 90IS	RA6258(Included)		RA5258	RA5258			RA5258		RA6258(Included)	Universal adapter (included)				
	Powershot Pro1	RA6258(Included) *10*3		RA5258*10*3					IE6257 *10*19	IE6257*10	Universal adapter (included) *10	Universal adapter (included) *10*3			
	EOS300D+EF-S18-55mm Zoom lens	RA6258*3		RA5258					RA6258 (included)	RA6258 (included)	Universal adapter (included)	Universal adapter (included)			
CASIO	EX-P700/P600	RA6258(Included) *15*3	RA5258 *15	RA5258*15	RA5258*16	RA5258*16*3	RA5258*16	RA6258(Included)*16	RA6258(Included)*16	Universal adapter (included) *15					
	EX-P505	HD-2200PRO(2.2X)+RA3743(Included)*3	RA5243	RA5243	RA5243	RA5243	RA5243			MSN-200/MSN-500+RA3743	RA3743	RA3743			
	QV-5700/QV-4000/QV-3500		RT52475	RT52475	RT52475	RT52475	RT52475	RA6252(Included)+RT52475	RA6252(Included)+RT52475	Universal adapter (included) +RT52475					
EPSON	PhotoPC3100/PC3000Z		RT5246	RT5246	RT5246	RT5246	RT5246		RA6252(Included)+RT5246	Universal adapter (included) +RT5246					
FUJIFILM	FinePix S5200/S5600*NEW!	RA6255		RA5255	RA5255	RA5255	RA5255	RA6255*38	RA6255*37	Universal adapter (included)	Universal adapter (included)	Universal adapter (included)	RA4952(Included)+RA5255	RA5852+RA5255	
	FinePix S9000/S9500	RA6258(Included)		RA5258				RA6258(Included)*33	RA6258(Included)*34	Universal adapter (included)	Universal adapter (included)	Universal adapter (included)			
	FinePix S5000	RA6252(Included)+RT5249	RT5249*29	RT5249	RT5249	RT5249	RT5249	RA6252(Included)+RT5249*20	RA6252(Included)+RT5249	Universal adapter (included)+RT5249					
	FinePix S20Pro/S7000/S602	RA6252(Included)+RT5255*3	RT5255	RT5255	RT5255	RT5255 *3	RT5255	RA6252(Included)+RT5255*19	RA6252(Included)+RT5255	Universal adapter (included) +RT5255					
	FinePix S3000/S304/3800	RA6252(Included)+RA5255 *3*4	RA5255 *4	RA5255 *4	RA5255 *4	RA5255 *4	RA5255 *4	RA6252(Included)+RA5255*4	RA6252(Included)+RA5255*4	Universal adapter (included) *4					
FinePix 4900Z/6900Z	RA6252(Included)+RT5255	RT5255	RT5255	RT5255	RT5255	RT5255*3	RT5255	RA6252(Included)+RT5255	RA6252(Included)+RT5255	Universal adapter (included) +RT5255			RA4952(Included)+RT5255		
KONICA MINOLTA	DiIMAGE Z6*NEW/Z5/Z3	RA6252(Included)+RT5246Z3		RT5246Z3	RT5246Z3	RT5246Z3	RT5246Z3	RA6252(Included)+RT5246Z3	RA6252(Included)+RT5246Z3	Universal adapter (included) +RT5246Z3	Universal adapter (included)+RT5246Z3	Universal adapter (included)+RT5246Z3	RA4952(Included)+RT5246Z3		
	DiIMAGE Z1/Z2	RA6252(Included)+RT5245MD		RT5245MD	RT5245MD	RT5245MD	RT5245MD	RA6252(Included)+RT5245MD	RA6252(Included)+RT5245MD	Universal adapter (included) +RT5245MD					
	DiIMAGE A200/A2/A1/7Hi/7i/7	RA6252(Included)+RA5249 *3		RA5249 *3				RA6252(Included)+RA5249*19	RA6252(Included)+RA5249	Universal adapter (included) +RA5249*3			Direct		
KYOCERA	M410R	RA6252(Included)+*23		*23	*23	*23	*23	RA6252(Included)*23	RA6252(Included)*23	Universal adapter (included) *23					
	M400R	RA6252(Included)+RT5249		RT5249	RT5249	RT5249	RT5249	RA6252(Included)+RT5249	RA6252(Included)+RT5249	Universal adapter (included) +RT5249					
Nikon	CoolPix 8800	RT6265T/W		RA5262+RT6265T/W				RT6265T/W*19	RT6265T/W	Universal adapter (included) +RT6265T/W	Universal adapter (included)+RT6265T/W				
	CoolPix 8700/5700	RA6252(Included)+RT5253NT	RT5253NT*29	RT5253NT	RT5253NW	RT5253NW*6		RA6252(Included)+RT5253NW	RA6252(Included)+RT5253NW	Universal adapter (included) +RT5253NT			RA4952(Included)+RT5253NW		
	CoolPix 5400	RA6252(Included)+RT5245NT *3	RT5245NT	RT5245NT				RA6252(Included)+RT5245	RA6252(Included)+RT5245	Universal adapter (included) +RT5245NT	Universal adapter (included)+RT5245NT	Universal adapter (included)+RT5245NT			
	CoolPix 5000	RA6252(Included)+RT5246N	RT5246N	RT5246N				RA6252(Included)+RT5246N	RA6252(Included)+RT5246N						
	CoolPix 4500/995										Direct	Direct			
	CoolPix 4300/885/880/775										Direct	Direct			
	CoolPix 990/950/800										Direct	Direct			
OLYMPUS	SP-500UltraZoom*NEW	RA6252(Included)+RT5245C7		RT5245C7	RT5245C7	RT5245C7	RT5245C7	RA6252(Included)+RT5245C7*38	RA6252(Included)+RT5245C7*37	Universal adapter (included)	Universal adapter (included)+RT5245C7	Universal adapter (included)+RT5245C7	RA4952(Included)+RT5245C7	RA5852+RT5245C7	
	C-8080WideZoom	RA6252(Included)+RT5267CT*3	RT5267CT*3	RT5267CT*3				RT6267CW*19	RT6267CW	Universal adapter (included) +RT5267CT*3	Universal adapter (included)+RT5267CT*3	Universal adapter (included)+RT5267CT*3			
	C-7070WZ/5060WZ	RA6252(Included)+RT5248	RT5248*29	RT5248	RT5248			IE6252+RT5248	IE6252+RT5248	Universal adapter (included) +RT5248	Universal adapter (included)+RT5248	Universal adapter (included)+RT5248	RA4952(Included)+RT5248		
	C-5050Zoom	RA6252(Included)+RT5241 *3	RT5241	RT5241	RT5241			IE6252(Included)+RT5241	IE6252(Included)+RT5241	Universal adapter (included) +RT5241			RA4952(Included)+RT5241		
	C-4040/4100/4000/3040/3030/3100/3000/2040Z		RT5241	RT5241	RT5241	RT5241	RT5241*3	RT5241	IE6252+RT5241 *only applies on C-2040/3040/4040	RA6252(Included)+RT5241	Universal adapter (included) +RT5241				
	C-2500L		RA5243	RA5243	RA5243*3	HD-6600PRO(43)	RA5243		RA6252(Included)+RA5243		Direct				
	C-2100Zoom	RA6252(Included)+RA5249		RA5249	RA5249		RA5249		RA6252(Included)+RA5249	Universal adapter (included) +RA5249					
	C-770/765/760/755/750/745/740/730/720/700UZ	RA6252(Included)+RT5245C7		RT5245C7	RT5245C7	RT5245C7	RT5245C7	RT5245C7	RA6252(Included)+RT5245C7	RA6252(Included)+RT5245C7	Universal adapter (included) +RT5245C7				
	D-860L/360L/340L														
	D-460Z/450Z														
	E-20/E-10/E-20P/E-20N	Direct Mount *3	RA5262 *3	RA5262 *3					Direct Mount*19	Direct Mount	Universal adapter (included) *3				
E-100RS	RA6252(Included)+RA5249		RA5249	RA5249		RA5249			RA6252(Included)+RA5249	Universal adapter (included)+RA5249					
Panasonic	Lumix DMC-FZ30	RA6252(Included)+RA5255		RA5255		HD-6600PRO(55)	RA5255	RA6252(Included)+RA5255*35	RA6252(Included)+RA5255*36	Universal adapter (included)	Universal adapter (included)	Universal adapter (included)			
	Lumix DMC-FZ20/FZ10	RA6252(Included)+RT5264P		RT5264P	RT5264P	RT5264P*3	RT5264P	RA6252(Included)+RT5264P*19	RA6252(Included)+RT5264P	Universal adapter (included) +RT5264P	Universal adapter (included)+RT5264P	Universal adapter (included)+RT5264P	RA4952(Included)+RT5264P		
	Lumix DMC-FZ5	RA6252(Included)+RA5255 *2		RA5255 *2			RA5255 *2	RA6252(Included)+RA5255*2	RA6252(Included)+RA5255*2	Universal adapter (included) *2					
	Lumix DMC-FZ3/FZ2/FZ1	RA6252(Included)+RA5255 *2		RA5255 *2	RA5255 *2	RA5255 *2*3	RA5255 *2	RA6252(Included)+RA5255*2*19	RA6252(Included)+RA5255*2	Universal adapter (included) *2					
SANYO	IDC-1000Z		Direct	Direct	Direct	Direct	Direct		RA6252(Included)	Universal adapter (included)					
SONY	DSC-F828	RA6258(Included) *3	RA5258*29	RA5258				RA6258(Included)*19	RA6258(Included)	Universal adapter (included)*3	Universal adapter (included)*3	Universal adapter (included)*3			
	DSC-F717/F707	RA6258(Included) *3	RA5258 *6	RA5258	RA5258	RA5258	RA5258	RA6258(Included)	RA6258(Included)	Universal adapter (included)					
	DSC-F505(V/K)		Direct	Direct	Direct	Direct	Direct		RA6252(Included)	Universal adapter (included)					
	DSC-H1 12X Zoom	RA6258(Included)*30		RA5258*30				RA6258(Included)*30	RA6258(Included)*30	Universal adapter (included)*30	Universal adapter (included)*30	Universal adapter (included)*30		Direct*30	
	HDR-HC1 Camcorder	RA6252(Included)+RA5237		RA5237	RA5237	RA5237	RA5237	RA6252(Included)+RA5237*31	RA6252(Included)+RA5237*32	Universal adapter (included)+RA5237	Direct	Direct		RA5837	
	DSC-P150/P100		HD-2200PRO(2.2X) or DVR-2020*27					HD-3031PRO*27	HD-3031PRO*27	MSN-200/MSN-500*27	*27	*27			
	DSC-P10/P8		DVR-2020(2.0X)*28		DVM-700*28	DVM-700*28	HD-5005PRO*28		HD-3031PRO*28	MSN-200/MSN-500*28	*28	*28			
	DSC-S85/S75/S70		RT5245	RT5245	RT5245	RT5245	RT5245	RA6252(Included)+RT5245	RA6252(Included)+RT5245	Universal adapter (included) +RT5245					
	DSC-V3	RA6252(Included)+RT5248V3*3	RT5248V3	RT5248V3				RA6252(Included)+RT5248V3	RA6252(Included)+RT5248V3	Universal adapter (included) +RT5248V3				RA4952(Included)+RT5245VW	
	DSC-V1	RA6252(Included)+RT5245VT *3	RT5245VT	RT5245VT	RT5245VW	RT5245VW	RT5245VW	RA6252(Included)+RT5245VT	RA6252(Included)+RT5245VT	Universal adapter (included) +RT5245VT				RA4952(Included)+RT5245VW	
	DSC-W7/W5/W1		HD-2200PRO(2.2X) or DVR-2020*24						HD-3031PRO*24	HD-3031PRO*24	MSN-200/MSN-500*24	*24	*24		
	MVC-CD500/CD400/CD300		RT5245	RT5245	RT5245	RT5245	RT5245	RA6252(Included)+RT5245	RA6252(Included)+RT5245	Universal adapter (included) +RT5245					

*1: Use with Canon LA-DC58B adapter. *2: Use with FZ5/FZ3/FZ2/1 Original adapter. *3: The lens will cause vignetting (darkening at corners). *4: Use with Fujifilm original hood adapter. *6: Set the camera's F stop slower than F5.6.(F5.6/F6.3/F7.1/F8.0) *10: Use with Canon LA-DC58C adapter. *11: Use with Canon LA-DC58D adapter. *12: Use with Canon LA-DC52D adapter. *13: Use with Canon LA-DC52C adapter. *14: Use with LAH-DC10 adapter. *15: Use with Casio LU-60A Tele adapter. *16: Use with Casio LU-60A Wide adapter. *18: Use with LAH-DC20 adapter. *19: Unable to take diagonal fisheye image by zooming. *20: Unable to take circular fisheye image. *21: Use with Canon LA-DC52 adapter. *22: Use with Canon LA-DC52B adapter *23: Use with camera's original adapter. *24: Use with SONY VAD-WA adapter & Raynox RA3730 adapter. *25: Use with Canon LA-DC52F adapter. *26: Use with Canon LA-DC10 adapter. *27: Use with SONY VAD-PHB adapter & Raynox RA3730 adapter. *28: Use with SONY VAD-PHA adapter & Raynox RA3730 adapter. *29: it reduces its resolution power at corners of the image. *30: Use with a female 58mm size adapter included in SONY DSC-H1 Camera. *31: Unable to take circular fish-eye image (able to take on still mode:4:3 at most wide angle position), but able to take diagonal fish-eye image by zooming around 1.5X. *32: Unable to capture a 180 degree image on diagonal lines at most wide angle position. *33: Performs a circular fish-eye effect at about F=15.4mm without vignetting. *34: It turns out to a diagonal fish-eye without vignetting at about F=8.1mm FL position. *35: Performs a circular fish-eye effect. Unable to take diagonal fish-eye image. *36: Achieving a diagonal fish-eye angle without vignetting at about F=8.1mm FL. *37: No vignetting occurs but unable to capture a fish-eye image at the max.wide position. *38: Not performs a circular fish-eye effect. Able to capture a diagonal fish-eye image by zooming.